BERGHOFF GB X5 PRO CARE INFORMATION



The BergHOFF X5 Pro handheld food processor is designed to help you make delicious meals while simplifying previously arduous tasks. To make sure that it works for years to come, simply follow these care guidelines.

BEFORE FIRST USE

Before you use your X5 Pro for the first time, you'll need to give it a quick clean to get it ready for use. Although the blades are dishwasher safe, for the first time, wash them with warm water, mild soap and a non-abrasive sponge. Do what you can to make sure that the motor unit, plug and cable do not become submerged in water.

OPERATING INSTRUCTIONS

Before trying out new recipes with your X5 Pro, make sure that when you are assembling or disassembling that your appliance is unplugged. It is also important to make sure that all of the components are properly attached before they're connected to a power source. When you're using the X5 Pro, make sure that it is not operated for longer than 1 minute continuously to avoid the device overheating. If you're blitzing hard food, we recommend that you limit to 10 second pulses. The X5 Pro also comes complete with a one-touch button with a digital display so that you can control and adjust speed for various tasks.

CLEANING AND MAINTENANCE



After each time you've used the X5 Pro, unplug the appliance and take apart the detachable blades. You can then either put the blades into the dishwasher, or clean with warm soapy water. If you need to clean the motor unit, use nothing more than a damp cloth - the motor unit should not be submerged in water. If you've made something that is high in salt, rinse the blades thoroughly under warm water before placing into a dishwasher. When you're removing the blades from your food processor, make sure to use the blade remover provided to avoid accidentally cutting yourself on the sharp titanium tipped blades.

We also recommend that in order to extend the lifespan of your X5 Pro, that you oil it every few months. To do this, simply remove the blades and hold the appliance upside down - add a few drops of oil (ideally vegetable oil - not olive oil) to the shaft and switch on the X5 Pro for 90 seconds. After this use a cloth with warm soapy water to clean. Always unplug while you are putting the oil into the unit and while cleaning.

STORAGE

After you've cleaned your device, please ensure that all parts are completely dry before reassembling. You will be provided with a case to store the X5 pro and all the accessories, we recommend storing it there to protect it from damage and dust accumulation.

SAFETY PRECAUTIONS

UNPLUG

If you're not using the device, make sure that it is unplugged. If you notice any damage to the cord or to the plug, contact BergHOFF and do not use the device.

NOT SUITABLE FOR CHILDREN

The blades of the X5 Pro are incredibly sharp, so it is not be suitable for children to use without supervision. Make sure that when it is stored, it is stored out of reach of children.